

RGBW Product Installation Notes



Please read before installation!

Agualux RGBW products require particular wiring & control gear

Aqualux RGB lights are wired via seperate power & control signal circuits. This is done to minimise potential EMI effects and to allow for a seperate power cable that can be sized according to the system load.

Key Points

- 24V DC to RGB Controller
- 24V DC to RGB Light
- RGBW Signal to RGBW Light

24VDC RGBW Controller Light Fitting Cable

Red	Red
Green	Green
Blue	Blue
White	Yellow
	Rlank (2/





Call 1300-662-644 for installation questions or visit www.aqualux.com.au